Panasonic, ideas for life



Hybrid IPPBX System

Quick Reference Guide

Model KX-T7730

Panasonic®

Proprietary Telephones

Quick Reference Guide

Model KX-T7730

Important Information

When using the KX-T7730, keep the following conditions in mind.

- If there is any problem, unplug the extension line and connect a known working phone. If
 the known working phone operates properly, have the defective phone repaired by a
 specified Panasonic Factory Service Centre. If the known working phone does not
 operate properly, check the KX series Business Telephone Systems and the internal
 extension wiring.
- Keep the unit away from heating appliances and electrical noise generating devices such as fluorescent lamps and motors.
- The unit should be kept free of dust, moisture and vibration, and should not be exposed to direct sunlight.
- Do not use benzine, thinner, or any abrasive powder to clean the cabinet. Wipe it with a soft cloth.
- Do not disassemble this product. Dangerous electrical shock could result. The unit must only be disassembled and repaired by qualified service technicians.
- Do not use any handset other than a Panasonic handset.
- Never attempt to insert wires, pins, etc, into the vents or other holes of this unit.
- When a failure occurs which exposes any internal parts, disconnect the telephone line cord immediately and return the unit to a service centre.

WARNING.

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR ANY TYPE OF MOISTURE.

THIS HANDSET EARPIECE IS MAGNETISED AND MAY RETAIN SMALL FERROUS OBJECTS.

IMPORTANT NOTICE:

Under power failure conditions, this telephone may not operate. Please ensure that a separate telephone, not dependent on local power, is available for use in emergencies.

This Class B digital apparatus complies with Canadian ICES-003.

Notes:

- In this manual, the suffix of each model number is omitted.
- For further information, refer to the Business Telephone System Manuals.
- This product is intended to be connected to Panasonic KX series Business Telephone System.

Features List

 $\stackrel{\text{co}}{\longleftarrow} \text{Outside (CO) Line button} \quad \stackrel{\text{co}}{\longleftarrow} \text{Off-hook} \quad \boxed{\qquad} \text{Feature number} \quad {} \boxed{ \begin{pmatrix} u \\ u \end{pmatrix}} \quad \text{Talk}$

* "Location of Controls" is shown on page 8.


Desired Function	Operation		
	Making Calls		
Calling	To an extension To an external party P(t/2) To an external party P(t/2) Phone no. ► ((t/2)		
Redial	Partial ► Control of the Control of		
One-Touch Dialling	To program PROGRAM 9 9 ▶ □ ▶ 2 phone no. ▶ United Dial. PROGRAM STORE PROGRAM PROGRAM PROGRAM		
	To dial assigned as a One-touch dialling button		
Calling an operator			
Speed Dialling (Personal)	To set		
	To dial Note: The personal speed dial no. It is the personal speed dial		
Speed Dialling (System)	To dial AUTO DIAL System speed dial no. ► ((1))		
	Receiving Calls		
Handsfree answerback	While on-hook AUTO ANS MUTE		
Picking up a call	Outside (CO) Line 4 * Directed 4 1 • extension no. Group 4 0		

Desired Function	Operation				
	When the Dialled Extension is Busy/No Answer				
Automatic Callback Busy	To set While hearing a busy tone G F F F F F F F F F F F F F F F F F F				
Message Waiting	Sender	To leave a notification MESSAGE O To cancel a notification ↑ To cancel a notification			
	Receiver	To call back MESSAGE MESSAGE MESSAGE MESSAGE			
		To clear all notifications ↑ 0 0 ▶ receiver's extension no. The state of the st			
Call Waiting	Sender	While hearing a busy tone 1 ▶ Wait for an answer. ▶ (((4))			
	Receiver	To talk to the new party While hearing the Call Waiting tone HOLD CO Note: If the current call and new call are intercom calls, connection with the new call is established as soon as you press the HOLD button.			
During a Conversation					
Holding a call	Holding	To retrieve a call at the holding extension			
	To retrieve an outside call from another extension				
Holding a call exclusively	Holding HOLD				
Transferring a call	TRANSFER	extension no. to an extension phone no. to an external party			

Features List

Desired Function	Operation		
	Useful Features		
Paging	All extensions All extensions Group All external speakers 3 2 0 Specific external speaker no. All extensions & external speakers 3 2 ** (Check the type of your Main Unit.)		
	To answer an announced page Through a telephone speaker 4 3 Through an external speaker 4 2 external speaker no.		
Three-party conference	third party's no.		
Setting Absent Message	► 7 5 0 ► message no. ► parameter (if required) ► →		
Log-In/Log-Out	For Log-Out For Log-Out		

Features List




^{*} Consult your dealer for more details about the feature access numbers.

^{*} Some feature access numbers may be different in each market. Please consult your local dealer for the details.

^{*} For KX-TD500 users, DN buttons cannot be assigned.

Location of Controls

RINGER Volume Selector



^{*} Headset (not included)

- **PROGRAM:** Used to enter and exit the programming mode.
- CONF (Conference): Used to establish a multiple party conversation.
- 3 INTERCOM: Used to make or receive intercom calls.
- FWD/DND (Call Forwarding/Do Not Disturb): Used to perform Call Forwarding or Do Not Disturb.
- **5** FLASH/RECALL: Used to disconnect the current call and make another call without hanging up.
- 6 AUTO ANS (Auto Answer): Used to receive an incoming call in the hands-free mode.

MUTE: Used to mute the microphone during a conversation.

- **AUTO DIAL/STORE:** Used for speed dialling or storing program changes.
- 8 TRANSFER: Used to transfer a call to another party.
- 9 REDIAL: Used to redial the last dialled number.
- **MOLD:** Used to place a call on hold.
- **SP-PHONE:** Used for the handsfree operation.

- 12 NAVIGATOR KEY: Used to adjust the volume and the display contrast or select desired items for each function.
- 13 Flexible Outside (CO) Line Button:
 Used to make or receive an outside call.
 Pressing this button seizes an idle outside
 line automatically. (Button assignment is
 required.) Also used as the desired
 function buttons. (Button assignment is
 required.)
- PAUSE: Used to insert a pause during dialling.
- **MESSAGE:** Used to leave a message waiting indication or call back the party who left the message waiting indication.
- **Message/Ringer Lamp:** The Message/ Ringer lamp informs you visually that you have a message or a call.
 - When you receive a call, the lamp flashes depending on the ringing pattern. When someone has left you a message, the lamp is lit continuously.
 - When the ringing pattern is set to Single (Slow flash), Double (Moderate flash), or Triple (Rapid flash) in your Business Telephone System, the lamp flashes. When the other ringing patterns are set in your PBX, the lamp may not flash. (e.g., S-Double, Call Waiting Tone1).

Initial Settings

◆ Speaker volume *

While in on-hook or during a conversation







Press SP-PHONE.

Press Up or Down.

◆ Handset/Headset volume *

While using a handset or headset



Press Up or Down.

♠ Ringer volume

While in on-hook or receiving a call



Slide the lever of the **RINGER** Volume Selector to the desired setting (**HIGH/LOW/OFF**).

♦ Display contrast *


While in on-hook or receiving a call



Press Left or Right.


* The above settings may return to default settings if the telephone line cord is disconnected or the main unit's power is interrupted.

Connection




Wall Mounting


1 Pull down the handset hook until it locks, so the tab holds the handset.



2 Remove the attached stand.




3 Mount the unit on the wall.



To temporarily place the handset down during a conversation,

hook it over the top edge of the phone as shown.



Panasonic Canada Inc. 5770 Ambler Drive, Mississauga, ON L4W2T3	
© 2003 Panasonic Communications Co., Ltd. All Righ	nts Reserved.
	PSQW2024ZA KK0403TT0