Panasonic®

Digital Proprietary Telephone

Quick Reference Guide

Model No. KX-T7667

Important Information

When using the KX-T7667, keep the following conditions in mind.

- If there is any problem, unplug the extension line and connect a known working phone. If
 the known working phone operates properly, have the defective phone repaired by a
 specified Panasonic Factory Service Centre. If the known working phone does not
 operate properly, check the KX-TDA series Business Telephone Systems and the
 internal extension wiring.
- Keep the unit away from heating appliances and electrical noise generating devices such as fluorescent lamps, motors and televisions. These noise sources can interfere with the performance of the unit.
- This unit should be kept free of dust, moisture, high temperature (more than 40 °C) and vibration, and should not be exposed to direct sunlight.
- Do not use benzine, thinner, or the like, or any abrasive powder to clean the cabinet. Wipe it with a soft cloth.
- Do not use any handset other than a Panasonic handset.
- Do not disassemble this product. Dangerous electrical shock could result. The unit must only be disassembled and repaired by qualified service technicians.
- When a failure occurs which exposes any internal parts, disconnect the telephone line cord immediately and return this unit to service centre.
- Never attempt to insert wires, pins, etc, into the vents or other holes of this unit.

WARNING:

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR ANY TYPE OF MOISTURE.

THE HANDSET EARPIECE IS MAGNETISED AND MAY RETAIN SMALL FERROUS OBJECTS.

DISCONNECT THE TELEPHONE LINE CORD FROM THIS PRODUCT IF THIS PRODUCT EMITS SMOKE, AN ABNORMAL SMELL OR MAKES UNUSUAL NOISE. THESE CONDITIONS CAN CAUSE FIRE OR ELECTRIC SHOCK. CONFIRM THAT SMOKE HAS STOPPED AND CONTACT AN AUTHORISED SERVICE CENTRE.

IMPORTANT NOTICE:

Under power failure conditions, this telephone may not operate. Please ensure that a separate telephone, not dependent on local power, is available for use in an emergency.

Note: • In this manual, the suffix of each model number is omitted.

• This Class B digital apparatus complies with Canadian ICES-003.

Important Safety Instructions

When using this unit, basic safety precautions, including those below, should always be followed to reduce the risk of fire, electric shock and injury to persons.

- 1. Read and understand all instructions.
- 2. Follow all warnings and instructions marked on this unit.
- Unplug this unit from the main unit before cleaning. Do not use liquid or aerosol cleaners. Clean with a damp cloth.
- Do not use the unit near water, for example, near a bathtub, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool.
- Place this unit on a flat surface.
 Serious damage and/or injury may result if the unit falls.
- 6. The unit should never be placed near or over a radiator or other heat source.
- Do not allow anything to rest on the extension cord. Do not locate this unit where the cord may be stepped on or tripped on.
- To reduce the risk of fire or electric shock, do not overload wall outlets and extension cords.
- Do not insert objects of any kind into this unit through openings, as they may touch dangerous voltage points or short out parts that could result in a risk of fire or electric shock. Never spill liquid of any kind on the unit.
- 10. To reduce the risk of electric shock, do not disassemble this unit. Only qualified personnel should service this unit. Opening or removing covers may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock.

- 11. Unplug this unit from the main unit and have the unit serviced by qualified service personnel in the following cases:
 - A. When the extension cord is damaged or frayed.
 - B. If liquid has been spilled on the unit.
 - C. If the unit has been exposed to rain or water.
 - D. If the unit does not work normally by following the manual. Adjust only controls covered by the manual. Improper adjustment may require repair by an authorized service centre.
 - E. If the unit has been dropped, or damaged.
 - F. If the unit's performance deteriorates.
- 12. Avoid using a telephone (other than a cordless type) during an electrical storm. There is a remote risk of electric shock from lightning.
- 13. Do not use the telephone in the vicinity of a gas leak to report the leak.

SAVE THESE INSTRUCTIONS


(co)	Outside (CO) Line button	Off-hook	On-hook	Feature number	Guz:	Talk
(ICD Grou	Incoming Call Distribut	on Group button	(DSS) Direc	t Station Selection button	1	
C. Tone	Confirmation Tone	Ringback To	one			

o. Totle					
Feature	Operation				
Making Calls					
Calling	To an extension To an outside party extension no. Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Coo Co				
Redial	PEDIAL > ((i/2)				
Quick Dialling	P (quick dial no.) ► (\(\lambda \cdot \c				
One-touch Dialling To store PROGRAM O L(CO) Dialling To dial assigned as a One-touch Dialling button AUTO DIAL PROGRAM O PROGRAM O AUTO DIAL PROGRAM O O O To dial assigned as a One-touch Dialling button					
Operator Call	\$ ► O ► (((\(\xi\)))				
Personal Speed Dialling	To store personal speed desired no. (2 digits) To dial AUTO DIAL STORE To store personal speed dial no. (2 digits) personal speed dial no. (2 digits) C. Tone				
System Speed Dialling	To dial AUTODAL System speed dial no. (3 digits) System speed dial no. (3 digits)				
Doorphone Call	★ 3 1 ► (doorphone no. (2 digits)				
Automatic Callback Busy	To set While hearing a busy tone 6				
During a Conversation					
To hold To retrieve a call at the holding extension HOLD C. Tone To retrieve an outside call from another extension To retrieve an outside call from another extension					

Feature	Operation				
During a Conversation					
Call Transfer	TRANSFER C. Tone (extension no.) To an extension outside party To an outside party				
	Useful Features				
Off-hook Monitor	To set/cancel During a conversation using the handset				
Call Park	To set TRANSFER				
	To retrieve stored parking cone no. (2 digits) C. Tone				
Multiple Party Conversation	To add other parties during a conversation CONF				
	To leave a conference CONF C. Tone				
Call Pickup	► (c) (DSS) ★ 4 1 Extension no. Directed C. Tone C. To				
Sending a Call Waiting Tone	While hearing a busy tone 1 ▶ Wait for an answer. ▶ \$\(\begin{align*} \lambda \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\				
Answering a Call Waiting	To hold the current call then talk to the new party HOLD CO / NITERCOM				

^{*} Disregard this step if both parties are extensions.


Feature	Operation				
	Useful Features				
Paging	To page *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *** *				
Message Waiting	To leave a message waiting indication When the called extension is busy or does not answer MESSAGE Called extension To call back extension To call back MESSAGE L(L) L(L)				
Log-in/Log-out	* 7 3 6 1 For Log-in				
	Before Leaving Your Desk				
Setting Absent Message	To set Note				
Call Forwarding	Busy No answer Busy/ No answer Co line access no. Description Busy/ No answer Co line access no. Description Co line access n				





- For more details, refer to the Business Telephone System User Manual or consult your dealer.
- You can change the flexible CO buttons to the feature buttons.
- "Location of Controls" is shown on page 7.

Location of Controls



- **PROGRAM:** Used to enter and exit the personal programming mode.
- **2 CONF (Conference):** Used to establish a multiple party conversation.
- **③ INTERCOM:** Used to make or receive intercom calls.
- FWD/DND (Call Forwarding/Do Not Disturb): Used to perform Call Forwarding or Do Not Disturb.
- **5** FLASH/RECALL: Used to disconnect the current call and make another call without hanging up.

3 AUTO ANS (Auto Answer)/MUTE:

Used to receive an incoming call in handsfree mode or mute the microphone/handset during a conversation.

- AUTO DIAL/STORE: Used for System/Personal Speed Dialling or storing programme changes.
- **TRANSFER:** Used to transfer a call to another party.
- REDIAL: Used to redial the last dialled number.
- **(1) HOLD:** Used to place a call on hold.
- **⑤** SP-PHONE (Speakerphone): Used for the hands-free operation.
- Navigator Key: Used to adjust the volume and select desired items for each function.
- B Flexible Outside (CO) Line Buttons:
 Used to make or receive an outside call.
 Pressing this button seizes an idle outside
 line automatically. (Button assignment is
 required.) Also used as feature buttons.
 (Button assignment is required.)
- PAUSE: Used to insert a pause during dialling.
- MESSAGE: Used to leave a message waiting indication or call back the party who left the message waiting indication.
- Message/Ringer Lamp: When you receive a call, the lamp flashes red. When someone has left you a message, the lamp stays on red.

Setting


◆Speaker/Ringer/Handset/Headset Volume

Speaker Volume	While in hands-free conversation	
Ringer Volume	While on-hook or receiving a call	
Handset/Headset Volume	While using the handset or headset	Press UP or DOWN.

LCD Contrast/Headset Mode



◆Ring Tone




* The ring tone pattern of patterns 09 to 30 is the same as pattern 01.


Settings on the Programming Mode

To ente	To enter the programme mode				To exit			
PROGRAM			PROGRAM					
Operation								
Loop-CO (L-CO)	(co) ►	★		FWD/DND - Both calls	(co) ► (4 1 >	AUTO DIAL STORE	
Single-CO (S-CO)	(co) ►	O CO line no.	AUTO DIAL STORE	FWD/DND - Outside calls	(;;) ► (4 2 ▶	AUTO DIAL STORE	
Direct Station Selection	(co) ►	1 extension no.	AUTO DIAL STORE	FWD/DND - Intercom calls	(co) ► (4 3 ▶	AUTO DIAL STORE	
One-touch Dialling	(co) ►	2 desired no.	AUTO DIAL STORE	Account	(co) ► (4 8 ▶	AUTO DIAL STORE	
Incoming Call Distribution	(co) >	3 0 ▶	AUTO DIAL	Conference	(co) ► (4 9 ▶	AUTO DIAL STORE	
Group (ICD Group)	> [10	CD Group no.	STORE	Log in/ Log-out	(co) ► 5 5 ►		AUTO DIAL STORE	
Preferred Line Assignment-Outgoing		1 9 ► US STORE	· ▶ ' <u>-</u> '	+ CO button no	Ar D. / (co) A bu	o line n idle outside line CO/ICD Group utton tercom	AUTO DIAL STORE	
Preferred Line Assignment-Incoming		2 0 ► U STORE	▶ 📑		a / 🖵 /	No line The longest ringing line An assigned outside button	AUTO DIAL STORE	
Alternate Receiving- Ring/Voice		2 1 > UD STORE		Ξ, `		AUTO DIAL STORE		
Call Waiting for Outside calls		3 0 ► 0 No (No tone) / 1 Yes (Tone) ► 0 STORE						
Call Waiting Selection		3 1 ► 0 No Call / 1 Tone/ 3 Whisper OHCA ► 5TORE						
Call Waiting Tone Type Selection		3 2 ► (STORE					
Extension PIN [Personal Identification Number] (PIN-max.10 digits)		9 0 P U STORE	STORE To change a stored extension PIN to new one					
Station Programming Data Default Set		##	O DIAL ORE	AUTO DIAL STORE				


Connection




1 Pull down the handset hook until it locks, so the tab holds the handset.



2 Remove the attached stand.



3 Mount the unit on the wall.



To temporarily place the handset down during a conversation, hook it over the top edge of the phone as shown.

